




ALIMENTAZIONE




OSC




DISPLAY




GPS




SD-CARD




KEYPAD




RESET




LD INDICATOR




IN




CONNETTORE CIRCUIT 2




WII




SELECT OUT




CIRCUIT 2




OUT LED CIRCUIT 2




OUT LED




IC MASTER



IC SLAVE



DFPLAYER



SPK

